

# IMPORTANT

## Special Safety Instructions

(Lid Attachment)




When you put the lid on the extractor you must be able to read the embedded writing on the lid (or warning label if applied). **STEP 1-** Hold the lid at a 45 degree angle. **STEP 2-** Place the plastic tees down on the right sides of the hinge. **STEP 3-** Slide to the left so that the left side of the tee goes in the secured bracket. Once it is secured you should be able to lay the lid down. **CAUTION:** While the lid is down the clear plastic should not be overlapping any part of the yellow hinge on either side.



STEP 1



STEP 2



STEP 3

**NOTE:** Please be sure to thoroughly clean the extractor prior to its return.



**Do not disassemble for cleaning. The ball bearing at bottom of shaft will fall out!**

### CAUTION

## Cleaning Instructions

Bottom of Barrel  
(inside) Ball Bearing  
The Shaft sits on Ball




To clean extractors, use warm to hot water with a soft cloth. Please do not use anything rough and abrasive on extractor. If the extractor is still not clean you may use a small amount of dish soap. There is no need to disassemble the extractor while cleaning it. If you feel the need to disassemble the extractor please be aware of the small ball bearing on the bottom of the extractor.

---

## Extracting

---

Frames should be uncapped prior to extracting. When extracting  $9\frac{1}{8}$ " (23.18cm) frames or  $6\frac{1}{4}$ " (15.88cm) frames with wax foundation, the frames will need to be rotated during extraction. Extract side one approximately 50%, turn the frame to side 2 and extract 100% , then return to side one and extract the remaining 50%. Rotating the frame will lessen the occurrence of blowouts in the foundation from the weight of the honey. If plastic foundation is used, it is possible to extract each side 100% before turning.  $5\frac{3}{8}$ " (13.65cm) frames are placed radially as shown below. It is not necessary to turn frames placed radially. Keep your honey gate open when extracting to ensure the basket moves freely. Your extractor is not intended to be a storage tank. Promptly move any honey to a storage container or bottling tank.



Holds 3  
 $9\frac{1}{8}$ " (23.18 cm)  
Frames



Holds 3  
 $6\frac{1}{4}$ " (15.88 cm)  
Frames



Holds 6  
 $5\frac{3}{8}$ " (13.65 cm)  
Frames